BODYGUARD® COMPOSITES

REV OCT 25, 2023

# ORDER OF INSTALLATION FOR FULL VAN KITS

## Ford Transit Mid Roof

1. Install the ceiling panel(s)
2. Install the B-Pillar vertical trim
3. Install the trim pieces:
   - A. Driver side B-Pillar top corner trim
   - B. Passenger side sliding door trim
   - C. Front ceiling trim
4. Install the rear driver and passenger walls
5. Install the front driver wall (if applicable)
6. Install the rear door trim

## Ford Transit High Roof / Ext.

1. Install the ceiling panel(s)
2. Install the B-Pillar vertical trim
3. Install the trim pieces:
   - A. Front ceiling trim
   - B. Driver side B-Pillar top corner trim
4. Install the rear driver and passenger walls
5. Install the driver and passenger wall extensions (if applicable)
6. Install the front driver wall (if applicable)
7. Install the rear door trim and passenger side sliding door trim

## Ram ProMaster Low / High Roof

1. Install the ceiling panel(s)
2. Install the rear driver and passenger walls
3. Install the front driver wall (if applicable)
4. Install the rear door trim and passenger side sliding door trim

## Ram ProMaster High Roof Ext.

1. Install the ceiling panel(s)
2. Install the rear driver and passenger walls
3. Install the rear driver and passenger wall extensions
4. Install the front driver wall (if applicable)
5. Install the rear door trim and passenger side sliding door trim

TOLL FREE: 1 877-859-8591
WWW.BODYGUARDCOMPOSITES.COM