



RAM PROMASTER BULKHEAD COVER INSTALLATION



VEHICLE COMPATIBILITY: RAM PROMASTER HIGH ROOF 159" WHEELBASE
ESTIMATED INSTALLATION TIME: 30 MINUTES

**MI-LIN1134-V01**

	QTY	DESCRIPTION	
A	23	10 X ¾ WASHER TOP PHILIPS BLACK TAPPING SCREW	
B	2	#3 ROBERTSON HEAD, NYLON SCREWS (45-10677)	
C	1	#3 SQUARE DRIVE BIT	
D	1	DRIVER SIDE FOAM CAP COVER (MI-LIN1132-V01)	
E	1	PASSENGER SIDE FOAM CAP COVER (MI-LIN1133-V01)	
F	1	BULKHEAD/AC COVER KIT (MI-LIN1131-V01)	

SUGGESTED TOOLS:

CORDLESS DRILL

**A Philips Black
Tapping Screw****B Nylon Screws
(45-10677)****C #3 Square
Drive Bit****D Foam Cap Cover
(Driver Side)****E Foam Cap Cover
(Passenger Side)****F Bulkhead
Cover Kit****Ensure you have all required hardware and equipment prior to beginning installation.**

WARNING: PRIOR TO DRILLING INTO THE VEHICLE, CHECK BEHIND DRILLING LOCATIONS FOR ELECTRICAL WIRES, FUEL/BRAKE LINES, AND OTHER CRITICAL COMPONENTS. ADJUST THE DRILLING LOCATIONS TO ENSURE THAT YOU AVOID CONTACT WITH THESE COMPONENTS. FAILURE TO DO SO CAN RESULT IN SERIOUS INJURY OR DEATH, AND CAUSE SEVERE DAMAGE TO THE VEHICLE'S FUNCTIONALITY.



Remove the factory-installed tray located in the bulkhead opening area.

(Set tray aside or discard as required.)



Position one foam cap cover over the exposed foam (driver or passenger side). Align the cover so it sits flush.

Secure the cover using one #3 Robertson screw (**B**). Drive the screw through the center dimple using a #3 square drive bit (**C**). Do not overtighten; finish tightening by hand to avoid stripping the nylon screw.

Repeat this process on the opposite side.



Lift the bulkhead panel into position above the foam cap covers. Align the panel with the bulkhead opening.

Using the pre-marked hole dimples as guides, fasten the panel in place with the provided self-tapping screws (**A**).

Ensure all screws are tightened and the panel is secure.



Installation is complete.